DT-308 JUMPER SETTING

- **JP1: EUP/WAKE ON OPTION**

  OPEN: To support EUP But no support LAN/Alarm/modem wake up & power fail after power on function

  Short : Disable EUP support but support LAN/Alarm/modem wake up & power fail after power on function　(Default)

- **JP3 : COM3/COM4 DC SUPPLY SELECT**

  Pin 1-3 Short：COM3 Pin1 connected as 12V DC

  Pin 3-5 Short：COM3 Pin1 connected as DCD

  Pin 2-4 Short：COM4 Pin1 connected as 12V DC

  Pin 4-6 Short：COM4 Pin1 connected as DCD

- **JP4 : COM3/COM4 DC SUPPLY SELECT**

  Pin 1-3 Short：COM3 Pin9 connected as 5V DC

  Pin 3-5 Short：COM3 Pin9 connected as RI

  Pin 2-4 Short：COM4 Pin9 connected as 5V DC

  Pin 4-6 Short：COM4 Pin9 connected as RI

- **JP5 : COM1/COM2 DC SUPPLY SELECT**

  Pin 1-3 Short：COM1 Pin9 connected as 5V DC

  Pin 3-5 Short：COM1 Pin9 connected as RI

  Pin 2-4 Short：COM2 Pin9 connected as 5V DC

  Pin 4-6 Short：COM2 Pin9 connected as RI

- **JP6 : COM1/COM2 DC SUPPLY SELECT**

  Pin 1-3 Short：COM1 Pin1 connected as 12V DC

  Pin 3-5 Short：COM1 Pin1 connected as DCD

  Pin 2-4 Short：COM2 Pin1 connected as 12V DC

  Pin 4-6 Short：COM2 Pin1 connected as DCD

- **JCMOS1 : CMOS DATA CONTROL**

  Pin 1-2 Short: Normal　(Default)

  Pin 2-3 Short : clear CMOS

PJ1 | COM2 | COM1 | USB1 | CR | LAN1

JP5 JP3

JP6 JP4

SYS_FAN1 DEBUG1

UPS

DT-308 COMPONENT SIDE

JP1

U19

LCD1

U8

LVDS1

MSR1

LED1

CN4 SW1

U37

U36

LPT

JCMOS1 CN3

VGA1

DT-308 SOLDER SIDE

SO-DIMM1