

## HT-4712 JUMPER SETTING

- **JCMOS1 : CMOS DATA CONTROL**  
Pin 1-2 Short: Normal  
Pin 2-3 Short : clear CMOS
- **JCOM\_SEL1 : COM1/COM2 Pin1 connected Setting**  
Pin 1-3 Short : COM1 Pin1 connected to 12V  
Pin 3-5 Short : COM1 Pin1 connected to DCD  
Pin 2-4 Short : COM2 Pin1 connected to 12V  
Pin 4-6 Short : COM2 Pin1 connected to DCD
- **JCOM\_SEL2 : COM3/COM4 Pin1 connected Setting**  
Pin 1-3 Short : COM3 Pin1 connected to 12V  
Pin 3-5 Short : COM3 Pin1 connected to DCD  
Pin 2-4 Short : COM4 Pin1 connected to 12V  
Pin 4-6 Short : COM4 Pin1 connected to DCD
- **JCR\_SEL1 : For CR open/close status port selection**  
Pin 1-3 & Pin 2-4 Short :for COM1  
Pin 3-5 & Pin 4-6 Short: for COM5
- **COM1~COM4 : +5V through BIOS ; VGA +12V through BIOS**  
Press F2 to access Chipset\PCH-IO Configuration\  
VGA DSUB 12V : Disabled  
COM1 DB9 5V : Disabled  
COM2 DB9 5V : Disabled  
COM3 DB9 5V : Disabled  
COM4 DB9 5V : Disabled

