

PP-9500K PCBA Ver.D later

※ SOFTWARE SWITCH 1 :

SWITCH 1			FUNCTION
1	2	Baud Rate	
OFF	OFF	115200	
OFF	ON	19200	
ON	OFF	9600	
ON	ON	38400	
3	4	Onboard Interface	
OFF	OFF	Ethernet	
ON	OFF	USB	
ON	ON	Serial	
5	6	7	Paper width & printable width
OFF	OFF	OFF	80mm, 512dots
ON	OFF	OFF	80mm, 576dots
OFF	ON	OFF	58mm, 424dots
ON	ON	OFF	58mm, 432dots
OFF	OFF	ON	83mm, 512dots
ON	OFF	ON	83mm, 576dots
OFF	ON	ON	83mm, 640dots
ON	ON	ON	83mm, 640dots
8			USB Class
OFF			Printer Class
ON			Virtual COM

※ SOFTWARE SWITCH 2 :

SWITCH 2	FUNCTION
1	Paper Feed Back
OFF	Enable
ON	Disable
2	Cut Paper after Cover Return
OFF	Enable
ON	Disable
3	Full Cut Paper
OFF	Disable
ON	Enable
4	Before Cut Paper
OFF	Normal Cut
ON	Cut and without paper feed
5	Busy condition
OFF	Enable
ON	Disable
6	< CR > Auto Line Feed
OFF	Disable
ON	Enable
7	Parity Check
OFF	NONE
ON	EVEN
8	Handshaking
OFF	DTR/DSR
ON	XON/XOFF

※ SOFTWARE SWITCH 3 :

SWITCH 3			FUNCTION
1			Raster Bitmap Printing
OFF			Batch Print
ON			Line Print
2	3	4	Print Speed
OFF	OFF	OFF	250
ON	OFF	OFF	300
OFF	ON	OFF	280
ON	ON	OFF	220
OFF	OFF	ON	200
ON	OFF	ON	180
5	6	7	Print Density
OFF	OFF	OFF	100%
ON	OFF	OFF	110%
OFF	ON	OFF	120%
ON	ON	OFF	130%
OFF	OFF	ON	90%
ON	OFF	ON	80%
OFF	ON	ON	70%
8			Thai Font mode
OFF			1 PASS
ON			3 PASS

※ SOFTWARE SWITCH 4 :

SWITCH 4		FUNCTION
1		Beep Sound after Cut paper
OFF		Disable
ON		Enable
2	3	Barcode Height Reduction
OFF	OFF	Disable
ON	OFF	Reduce 25%
OFF	ON	Reduce 50%
ON	ON	Reduce 75%
4	5	Line Space Reduction
OFF	OFF	Disable
ON	OFF	Reduce 25%
OFF	ON	Reduce 50%
ON	ON	Reduce 75%
6	7	Line Feed Reduction
OFF	OFF	Disable
ON	OFF	Reduce 25%
OFF	ON	Reduce 50%
ON	ON	Reduce 75%
8		Usb packet
OFF		Zero packet
ON		NAK packet

※ SOFTWARE SWITCH 5 :

SWITCH 5	FUNCTION
1	UPOS Write
OFF	Enable
ON	Disable
2	Reserve
OFF	
ON	
3	Reserve
OFF	
ON	
4	Reserve
OFF	
ON	
5	Reserve
OFF	
ON	
6	The New Font For “V” and “0”
OFF	Use Original Font
ON	Use New Font
7	The Beep Sound For “Paper Near End”
OFF	Enable
ON	Disable
8	The Beep Sound For “Paper Out”
OFF	Enable
ON	Disable

PP-9500K PCBA Ver.C before

※ SOFTWARE SWITCH 1 :

SWITCH 1			FUNCTION
1	2	Baud Rate	
OFF	OFF	115200	
OFF	ON	19200	
ON	OFF	9600	
ON	ON	38400	
3			USB Class
OFF			Printer Class
ON			Virtual COM
4			Onboard Interface
OFF			USB
ON			Serial
5	6	7	Paper width & printable width
OFF	OFF	OFF	80mm, 512dots
ON	OFF	OFF	80mm, 576dots
OFF	ON	OFF	58mm, 424dots
ON	ON	OFF	58mm, 432dots
OFF	OFF	ON	83mm, 512dots
ON	OFF	ON	83mm, 576dots
OFF	ON	ON	83mm, 640dots
ON	ON	ON	83mm, 640dots
8			Auto cutter
OFF			Enable
ON			Disable

※ SOFTWARE SWITCH 2 :

SWITCH 2	FUNCTION
1	Paper Feed Back
OFF	Enable
ON	Disable
2	Cut Paper after Cover Return
OFF	Enable
ON	Disable
3	Full Cut Paper
OFF	Disable
ON	Enable
4	Before Cut Paper
OFF	Normal Cut
ON	Cut and without paper feed
5	Busy condition
OFF	Enable
ON	Disable
6	< CR > Auto Line Feed
OFF	Disable
ON	Enable
7	Parity Check
OFF	NONE
ON	EVEN
8	Handshaking
OFF	DTR/DSR
ON	XON/XOFF

※ SOFTWARE SWITCH 3 :

SWITCH 3			FUNCTION
1			Raster Bitmap Printing
OFF			Batch Print
ON			Line Print
2	3	4	Print Speed
OFF	OFF	OFF	250
ON	OFF	OFF	300
OFF	ON	OFF	280
ON	ON	OFF	220
OFF	OFF	ON	200
ON	OFF	ON	180
5	6	7	Print Density
OFF	OFF	OFF	100%
ON	OFF	OFF	110%
OFF	ON	OFF	120%
ON	ON	OFF	130%
OFF	OFF	ON	90%
ON	OFF	ON	80%
OFF	ON	ON	70%
8			Thai Font mode
OFF			1 PASS
ON			3 PASS

※ SOFTWARE SWITCH 4 :

SWITCH 4		FUNCTION
1		Beep Sound after Cut paper
OFF		Disable
ON		Enable
2	3	Barcode Height Reduction
OFF	OFF	Disable
ON	OFF	Reduce 25%
OFF	ON	Reduce 50%
ON	ON	Reduce 75%
4	5	Line Space Reduction
OFF	OFF	Disable
ON	OFF	Reduce 25%
OFF	ON	Reduce 50%
ON	ON	Reduce 75%
6	7	Line Feed Reduction
OFF	OFF	Disable
ON	OFF	Reduce 25%
OFF	ON	Reduce 50%
ON	ON	Reduce 75%
8		Usb packet
OFF		Zero packet
ON		NAK packet

※ SOFTWARE SWITCH 5 :

SWITCH 5	FUNCTION
1	Reserve
OFF	
ON	
2	Reserve
OFF	
ON	
3	Reserve
OFF	
ON	
4	Reserve
OFF	
ON	
5	Reserve
OFF	
ON	
6	The New Font For “V” and “0”
OFF	Use Original Font
ON	Use New Font
7	The Beep Sound For “Paper Near End”
OFF	Enable
ON	Disable
8	The Beep Sound For “Paper Out”
OFF	Enable
ON	Disable