

BB-3000 Series Jumper Setting

※ DIP SWITCH 1:

SWITCH 1				FUNCTION
1		2		Baud Rate
OFF		OFF		1200
OFF		ON		2400
ON		OFF		4800
ON		ON		9600
3	4	5	6	Code Page
OFF	OFF	OFF	OFF	Page 1
ON	OFF	ON	OFF	Page 2
ON	OFF	ON	ON	Page 3
7		8		SWITCH MARK
OFF		OFF		NO MARK
OFF		ON		MARK S3.S4.S8.S9
ON		OFF		MARK S1.S2.S6.S7
ON		ON		NO MARK