

## PD-2300R Series Jumper Setting

RS-232 Format :

JP1	JP2	RS-232
Short	Short	9600,E,8,1
<b>Short</b>	<b>Opened</b>	<b>9600,N,8,1(Default)</b>
Opened	Short	19200,E,8,1
Opened	Opened	19200,N,8,1

Emulation Mode:

JP3	SW1		
	1	2	Mode
Short	ON	ON	UTC
Short	ON	OFF	Aedex
<b>Short</b>	<b>OFF</b>	<b>ON</b>	<b>Noritake(Default)</b>
Short	OFF	OFF	Epson
Opened	ON	ON	Futaba
Opened	ON	OFF	ADM
Opened	OFF	ON	Noritake+Hungary

Handshaking :

JP4	Handshaking
Short	Disable Check DSR Signal ( <b>PD-2301 Default</b> )
Opened	Check DSR Signal ( <b>PD-2300R Default</b> )