

PD-2600U Series Jumper Setting

RS-232 Format:

SW1		
1	2	RS232
ON	ON	Reserved
ON	OFF	Default
OFF	ON	Reserved
OFF	OFF	Reserved

Emulation Mode:

SW1			
3	4	5	Mode
ON	ON	ON	UTC
ON	ON	OFF	Aedex
ON	OFF	ON	Noritake(Default)
ON	OFF	OFF	Epson
OFF	ON	ON	Futaba
OFF	ON	OFF	ADM